

VK-CMG2LC Development Carrier Board How To



VK-CMG2LC v1.0 Development Carrier Board



Content:

1.	INTRODUCTION	3
1.1 1.2 1.3	Connectors Mux Dimensions	3 4 5
2.	POWER UP	6
3.	INSTALL U-BOOT (V2021.10)	6
3.1 3.2	INTO SPI FLASH	5
4.	BOOT LOGIC	7
5.	INSTALL LINUX (KERNEL V5.10.184)	8
5.1 5.2	INTO SD card \rightarrow Debian v12.4 (Bookworm)	8 9
6.	LAUNCH THE INSTALLED LINUX IMAGES	10
6. 7.	LAUNCH THE INSTALLED LINUX IMAGES	10 10
6. 7. 8.	LAUNCH THE INSTALLED LINUX IMAGES	10 10 11
 6. 7. 8. 8.1 8.2 8.3 8.4 8.5 8.6 8.7 8.8 	LAUNCH THE INSTALLED LINUX IMAGES. 1 APPLY OVERLAYS. 1 USE VARIOUS PERIPHERY IN LINUX. 1 AUDIO. 1 MIPI DSI DISPLAY. 1 MIPI CSI CAMERA. 1 ETHERNET. 1 USB. 1 PMOD (GPIO). 1 RS485 (UART). 1	10 11 11 11 12 13 14 15 16 17 18
 6. 7. 8. 8.1 8.2 8.3 8.4 8.5 8.6 8.7 8.8 9. 	LAUNCH THE INSTALLED LINUX IMAGES. 1 APPLY OVERLAYS. 1 USE VARIOUS PERIPHERY IN LINUX. 1 Audio. 1 MIPI DSI DISPLAY. 1 MIPI CSI CAMERA. 1 ETHERNET. 1 USB. 1 PMOD (GPIO). 1 RS485 (UART). 1 INSTALL MALI GPU DRIVER ON DEBIAN. 1	10 10 11 11 12 13 14 15 16 17 18 19



1. Introduction

<u>VK-CMG2LC</u> is development carrier board for <u>VK-CM-RZ/G2LC</u> System on Module. It is based on <u>Renesas</u> **R9A07G044C22GBG**, **Dual ARM Cortex-A55 + Cortex-M33 MCU**. The main purpose of this manual is to show how to get started with the module onboard.

1.1 Connectors



Connectors & Signals



1.2 Mux



Some of the periphery is available only when Mux is configured correctly:

- > **H 1** → Connects **PMOD2_PIN1** to PMOD1_CTS or PMOD1_INT.
- > **H 2** → Connects **PMOD2_PIN2** to PMOD1_TXD or P27_0.
- > **H 3** → Connects **PMOD2_PIN3** to PMOD1_RXD or I²C_SCL0.
- > **H** 4 \rightarrow Connects **PMOD2_PIN4** to PMOD1_RTS or I²C_SDA0.
- > **H 5** → Connects **PMOD2_PIN7** to PMOD1_INT or P23_1.
- > **H 6** → Connects **PMOD2_PIN8** to P27_0 or PMOD1_PIN8.
- \succ **H 7** \rightarrow Connects **P43_0** to UserBTN or PMOD1_PIN7
- $\succ~$ H 8 \rightarrow Connects P43_2 to PCAL9538A_INT or PMOD1_INT
- ▶ **H 9** \rightarrow Connects **P45_3** to PMOD1_PIN8 or I²S_SIN
- ▶ **H** 10 \rightarrow Connects P42_0 P42_4 to RS232C2 or USB1
- > H 11 → Connects P40_0 P40_1 & P41_0 P41_2 to RS232C1 or PMOD1-UART



1.3 Dimensions





2. <u>Power Up</u>

The board can be powered with from 2 sources:

- ➢ POWER connector (24 − 48 V)
- ≻ PoE

In idle state (without plugged periphery) the board consumes ~ **300 mA**. The consumption however, can jump up to ~ **1,2 A** (if Camera, Display, Ethernet, USB Flash, USB Keyboard, Audio jack & SD card are plugged in).

3. Install U-boot (v2021.10)

You can get the <u>U-boot</u> firmware from our site or compile it yourself from our <u>repository</u>, if you prefer manually building it from scratch.

- Connect VK-CMG2LC to the PC (through USB Type B micro) & see what COM port is assigned by the OS in the Device Manager.
- > Place a jumper in position 3-4 of the **SW4** (middle) to boot from the **SCIF0**.
- > Download vkPyFlasher rescue tool and launch it.
- > Download the U-boot **<u>firmware</u>** and unpack it in: **vkPyFlasher/images**.

3.1 into SPI Flash

> Run the following commands:

cd vkPyFlasher.

flash_boot.py --board=vkcmg2lc --serial_port=COM<n> --qspi.

- > Press reset button on the VK-CMG2LC
- > Wait the flashing to complete.

3.2 into eMMC SSD

Run the following commands:

cd vkPyFlasher.

flash_boot.py --board=vkcmg2lc --serial_port=COM<n>.

- > Press reset button on the VK-CMG2LC
- > Wait the flashing to complete.



After download is ready, remove the jumper from **SW4** to boot from **SPIBSC** (by default) and press **reset** => you should now be able to see the boot log of the U-boot.

```
COM75 - PuTTY
                                                                       Х
NOTICE: BL2: v2.9(release):c314a39-dirty
NOTICE: BL2: Built : 14:49:18, Sep 19 2023
NOTICE: BL2: Booting BL31
NOTICE: BL31: v2.9(release):c314a39-dirty
NOTICE: BL31: Built : 14:49:18, Sep 19 2023
U-Boot 2021.10 (Sep 20 2023 - 02:21:30 +0000)
CPU:
      Renesas Electronics CPU rev 1.0
Model: Vekatech vkrzg2lc
DRAM: 1.9 GiB
      watchdog@000000012800800
WDT:
WDT:
      Started with servicing (60s timeout)
MMC:
     sd@11c00000: 0, sd@11c10000: 1
Loading Environment from SPIFlash... SF: Detected mx25151245g with page size 25
6 Bytes, erase size 4 KiB, total 64 MiB
OK
In:
      serial@1004b800
      serial@1004b800
Out:
      serial@1004b800
Err:
U-boot WDT started!
Net:
Warning: ethernet@11c20000 (eth0) using random MAC address - ae:82:8e:b1:2b:1f
eth0: ethernet@11c20000
Hit any key to stop autoboot:
```

```
U-boot log
```

4. <u>Boot logic</u>

Understanding boot logic is crucial. As you see there are **2** copies of **U-boot** (1 in eMMC & 1 in SPI). Environment parameters of the ones are slightly different from the others. They are configured in such way, that when **SW4** is set to boot from eMMC (**no jumper**) it's U-boot searches Linux image in the same that **eMMC**, but when SW4 is set to boot from SPI (**1-2**) it's U-boot searches Linux image in **µSD** card. That's why default U-boot environment parameters differs on purpose and you don't need to edit them every time you want to boot from one or other media (you just set SW4). That actually explains why booting from SPI, leads to booting from µSD. You can always change those parameters & boot from wherever you want.



5. Install Linux (Kernel v5.10.184)

Now that you have 2 workable U-boot instances, up & running, it is time to load something bigger. You can get <u>Debian</u> Linux image from our site or compile <u>Yocto</u> yourself from our <u>repository</u>, (if you prefer building it from scratch):

5.1 into SD card → Debian v12.4 (Bookworm)

- > Get a **µSD** card with **min 4 G** capacity and plug it into the PC.
- > Download tool, named Rufus from <u>here</u>.
- > Unpack **debian-bookworm-vkcmg2lc.img.xz**.
- Launch Rufus, for Device select µSD card drive, for boot section select desired Linux image file (in this case debian-bookworm-vkcmg2lc.img).
- > Hit **START** & wait completion (Status **READY**), and eject µSD card from the PC.
- Plug µSD card into VK-CMG2LC's holder, set SW4 to connect (1-2) & press reset.
- > You should now be able to see login screen, use user: vkrz & password: vkcmg2lc.



Debian 12 login screen

> You can check for available package updates: **sudo apt-get update**.

If there are available upgrades such as in this case:

- 34 packages can be upgraded. Run 'apt list --upgradable' to see them.
- > You can install them: sudo apt-get upgrade.
- > If you want to extend the root partition to use the full capacity of the μ SD:

sudo growpart /dev/mmcblk1 2 && sudo resize2fs /dev/mmcblk1p2.



If you want to extend the root partition to a fixed size and form a new separate partition you should first install partition editor sudo apt-get install parted. Extend the root partition to N GB size: sudo parted /dev/mmcblk1 resizepart 2 NG. Fix filesystem block size: sudo resize2fs /dev/mmcblk1p2. Make new partition: sudo parted /dev/mmcblk1 "mkpart primary fat32 NG -1". Format the new partition: sudo mkfs.vfat -F 32 /dev/mmcblk1p3.

5.2 into eMMC SSD → Yocto v3.1.26 (Dunfell)

Get the **vkPyFlasher** prepared:

- Connect VK-CMG2LC to the PC (through USB Type B micro) & see what COM port is assigned by the OS in the Device Manager.
- > Connect VK-CMG2LC to the PC (through the lower USB Type A)
- > Remove any jumper from **SW4** to boot from the **eMMC**.
- Download the desired Linux image (<u>Yocto</u> / <u>Debian</u>), and place it at the location: vkPyFlasher/images/vkcmg2lc.

Flash the image:

- cd vkPyFlasher.
- In case you want Yocto:

flash_img.py --board=vkcmg2lc --serial_port=COM<n>

--image_rootfs=core-image-weston-vkcmg2lc.simg.

In case you want Debian:

flash_img.py --board=vkcmg2lc --serial_port=COM<n>

--image_rootfs=debian-bookworm-vkcmg2lc.simg.

- > Press **reset** button on the **VK-CMG2LC**.
- > Wait the flashing to complete.
- > Open the COM port assigned by the OS for the VK-CMG2LC with (115200|B|N|1) settings.
- Press reset once again.
- > Login to Yocto (user: **root**) or Debian (user: **vkrz** & password: **vkcmg2lc**).
- > In case of Debian, you can setup the partition on the fly:
 - \rightarrow Extend the root partition to use the full capacity of the eMMC:

sudo growpart /dev/mmcblk0 2 && sudo resize2fs /dev/mmcblk0p2.

> In case of Yocto, you should now be able to see login screen:



Putty COM75 - Putty	_		×
<pre>ted Hostname Service. [OK] Started User Manager for UID 0. [OK] Started Session c1 of user root. [12.485001] ravb 11c20000.ethernet eth0: Link is Up - 1Gbps/Full - flow contro. [12.492701] IPv6: ADDRCONF(NETDEV CHANGE): eth0: link becomes ready</pre>	l off		^
[12.539768] 8021q: 802.1Q VLAN Support v1.8 Poky (Yocto Project Reference Distro) 3.1.26 vkrzg2lc ttySC0			
BSP: RZG2LC/VK-RZ/G2LC-v1.0/3.0.5 LSI: RZG2LC Version: 2.0.5			
<pre>vkrzg2lc login: [44.764636] audit: type=1334 audit(1707914991.072:13): prog-id: [44.771664] audit: type=1334 audit(1707914991.072:14): prog-id=9 op=UNLOAD</pre>	=10 op	p=UNLOA	D
vkrzg2lc login:			~

Yocto Login screen

6. Launch the installed Linux images

Thanks to the convenient boot logic, launching is easy, it depends on correct setting of SW4

- > To boot Linux from μ SD: place a jumper to **SPIBSC (1-2)**.
- > To boot Linux from eMMC: remove the jumper from **eMMC (1-2)**.
- ➤ To boot Linux from Ethernet: set the switch to SPIBSC and make sure µSD slot is Empty. When U-boot can't find SD card, it will try to boot from its serverip, tftpdir & netrootfs environment parameters. (serverip is the address, where U-boot will look for NFS & TFTP servers, tftpdir shows where the boot directory is on the server and netrootfs → where root directory is on the server) Same server can be used to boot multiple boards, every board can have its own boot and root directories and that's why tftpdir and netrootfs parameters should be filled with the correct paths on the server.

7. <u>Apply Overlays</u>

Overlays are way to tell Linux to use or not a given periphery. They can even point a specific hardware for a same periphery and form configurations for different version of a board. For example in version 1, the board can use **Realtek** audio driver, in other **someone's else**, in third no audio at all. Management of the overlays is done through **uEnv.txt**, located in **/boot** directory of the particular linux image. This file is analyzed during boot of the Linux image, so every change in that file takes effect after boot. To apply overlay, you need to line it up in the following row:

fdt_extra_overlays= vkrz-dsi-kd070hdfia030.dtbo



All available overlays that can be applied are listed in **/boot/overlays**, but simultaneously only these can be activated at the same time.

- vkrz-cm33.dtbo
- vkrz-cm-scif2.dtbo / vkrz-cm-usb1.dtbo
- vkrz-csi-ov5645.dtbo
- vkrz-dsi-kd070hdfia030.dtbo / vkrz-dsi-kd101wxfid045.dtbo
- vkrz-qspi-mx25l51245g.dtbo
- vkrz-udma.dtbo

8. <u>Use various periphery in Linux</u>

To demonstrate using different periphery, we are going to use the Debian image, for other images (Yocto for example) the commands could be not available or could be slightly different, so don't worry if some of them do not work, just google how to do it for your particular distribution.

8.1 Audio

Audio is enabled by default and does not need overlay.



VK-CMG2LC Development How To manual rev. 0.1 Nov. 12, 2024



- > Plug headphones in the jack & type: aplay /usr/share/sounds/alsa/Noise.wav.
- You can also play it through the GUI: just go to Start/Sound & Video /Alsaplayer. press Add, browse to /usr/share/sounds/alsa/Noise.wav, press Play.
- You should now be able to hear white noise sample. If for some reason you can't here anything, open alsamixer and check if Card (in the upper left corner) is audio-da7212. If it is different, press F6 (Select sound card) and choose audio-da7212, also find Mixout Left DAC Left & Mixout Right DAC Right and make sure they are not Off.

		Als	aPlayer	_ = ×		
- Alter a	Speed: 10 Pan: cente	00% No er	stream	Volume: 100% 00:00 / 00:00		
			(B) []	1		
	d Unkno	wn Noise.wav		00:01		
	💠 Add	- Remove Shuffle	🗐 Open 🔲 Save	Clear		
🗼 Accessories 🕨						
Internet	Algoniauer					
System Tools	Alsaplayer					
Dreferences						
Preferences			vk	rz@vkrzg2lc: /m	nt	×
Run		File Edit Tabs	Help			
Logout		vkrz@vkrzg2lc:/m	nt\$			
	vkrz@vkrzg2lc:	AlsaPlayer				10:26 💻 🙆

AlsaPlayer application

8.2 MIPI DSI Display

Make sure you are applied one of these overlays in **/boot/uEnv.txt**. fdt_extra_overlays=vkrz-dsi-kd070hdfia030.dtbo/vkrz-dsi-kd101wxfid045.dtbo







8.3 MIPI CSI Camera

Make sure you are applied vkrz-csi-ov5645.dtbo overlay in /boot/uEnv.txt.

fdt_extra_overlays=vkrz-csi-ov5645.dtbo



- > Install tool to catch the video stream: sudo apt-get install vlc.
- > Download the CSI <u>v4l2-init</u> script and put it in the home directory (~).

If the hardware is available, the script will set default settings through these rows: media-ctl -d /dev/media0 -l "'rzg2l_csi2 10830400.csi2':1 -> 'CRU output':0 [1]" media-ctl -d /dev/media0 -V "'rzg2l_csi2 10830400.csi2':1 [fmt:UYVY8_2X8/\$imx219_res field:none]" media-ctl -d /dev/media0 -V "'imx219 0-0010':0 [fmt:UYVY8_2X8/\$imx219_res field:none]"

If default format (UYVY8_2X8) does not suit your needs, you can always change it.

- > When you are happy with settings in the script, execute it: ~/v4l2-init.sh.
- > Open VLC through the GUI: go to **Start/Sound & Video/VLC media player**.
- Go to Media → Open Capture Device ... → Capture Device Tab for Video device name select /dev/video0 and press Play.
- > You should now be able to see the video input stream.



8.4 Ethernet

Ethernet is enabled by default and does not need overlay. Plug the **cat** cable into **RJ45** connector and in a couple of seconds the board should get an **IP** from the local **DHCP** server.



- > You can check what IP is assigned: **sudo ifconfig**.
- > You can probe if Host is reachable: ping vekatech.com.



8.5 USB

USB0 (the lower) is enabled by default and does not need overlay, but if you want to use USB1 (the upper), remove any jumper on H10 and make sure you are applied **vkrz-cm-usb1.dtbo** overlay in **/boot/uEnv.txt**.

fdt_extra_overlays=vkrz-cm-usb1.dtbo.

Make sure vkrz-cm-scif2.dtbo is excluded, from fdt_extra_overlays, because it uses same pins as USB1. To test the USB, plug a device such as: Mouse, Keyboard, USB Flash, USB Camera & whatever other USB device you can think of.



- > Mouse: It is Plug & Play device, you don't need to do anything.
- > Keyboard: Also Plug & Play device, you don't need to do anything.
- > Flash Drive: most of the latest Linux distributions mounts the drive automatically, (Debian
- 12 is not an exception), so it is again another Plug & Play device.
- Camera: usually you need software to see the stream, the example below is with VLC, but ffmpeg or others are also a great choice.
 - \rightarrow Open VLC through the GUI: go to **Start/Sound & Video/VLC media player**.
 - \rightarrow Go to Media \rightarrow Open Capture Device ... \rightarrow Capture Devie Tab
 - for Video device name select /dev/video0 and press Play.
 - \rightarrow You should now be able to see the USB video stream.
- ▶ GSM Modem: Also Plug & Play device, but to set a connection it needs some setup:
- \rightarrow Make sure sudo apt-get install network-manager modemmanager are installed



- → Start their services: systemctl start NetworkManager ModemManager.
- \rightarrow If autostart on boot is a must: systemctl enable NetworkManager ModemManager.
- \rightarrow Configure GSM connection : sudo nmcli connection add type gsm ifname '*'
- con-name '<name>' apn '<AP>' connection.autoconnect yes.
- \rightarrow A new network interface, type **gsm** should appear: **nmcli device status**.

8.6 PMOD (GPIO)

GPIOs are enabled by default and do not need overlay.



Pay attention that **RZ_P23_0**, **RZ_P23_1 & RZ_P27_0** are on the **Low Voltage Power Domain** (i.e. their logical **HI** levels are **1,8V**) and take that in consideration when using these GPIOs.

- You have to tell the system which pin you want to manipulate. Let's say the pin is "Pport_pin". You have to calculate the internal pin number: (port x 8) + pin + 120, if P23_0 is desired to be controlled, the internal number is: (23 x 8) + 0 + 120 = 304. The way to tell the system is with these commands: sudo su
 echo 304 > /sys/class/gpio/export.
- If you want to get the value of P23_0 pin, you can type this: echo in > /sys/class/gpio/P23_0/direction. cat /sys/class/gpio/P23_0/value.
- If you want to set P23_0 pin to HI, you can type this: echo out > /sys/class/gpio/P23_0/direction. echo 1 > /sys/class/gpio/P23_0/value.
- If you don't want to use the pin anymore you can release the resource: echo 304 > /sys/class/gpio/unexport.



8.7 RS232 (UART)

UART1 is enabled by default and does not need overlay, but if you want to redirect it to RS232 interface put a jumper on H11 between (2-3). If you want to use UART2, put another jumper on H10 between (2-3) to also redirect it to RS232 and make sure you are applied **vkrz-cm-scif2.dtbo** overlay in **/boot/uEnv.txt**.

fdt extra overlays=vkrz-cm-scif2.dtbo.

Make sure vkrz-cm-usb1.dtbo is excluded, from fdt_extra_overlays, because it uses same pins as UART2.



- > Install port software: sudo apt-get install screen.
- > Short TX & RX together, so a Loopback test can be run.
- > Execute: screen /dev/ttySC2 Or screen -f /dev/ttySC2 (if flow control overlay)
- > Type something and you should now be able to see what you are typing.
- > If you remove the short, you won't see what you are typing.
- > Press **Ctrl+A** and then **K** to exit, (you may need to apply with **y**)



8.8 RS485 (UART)

RS485 is enabled by default and does not need overlay.



Set RS485 module to 19200 8 N 1 \rightarrow stty -F /dev/ttySC<n> 19200 cs8 -cstopb -parenb.

Init DE pin. RS485 is actually UART with Data Enable pin, which goes Hi before TX transaction and goes back to Low after the transaction, so you need to manually control that pin, this means the internal pin should be P5_1, which is (5 x 8) + 1 + 120 = 161. sudo su && echo 161 > /sys/class/gpio/export.

echo out > /sys/class/gpio/P5_1/direction.

echo 0 > /sys/class/gpio/P5_1/value.

> TX some data: echo 1 > /sys/class/gpio/P5_1/value. echo "Helow world" > /dev/ttySC3.

Wait data to be fully transmited & exec. echo 0 > /sys/class/gpio/P5_1/value.

RX some data: cat /dev/ttySC3.

Note that the receiving terminal can have buffering enabled, so the data read might not be displayed immediately. The buffer is flushed once enough data is entered, or when enough newlines are encountered.

Release DE pin resource: echo 161 > /sys/class/gpio/unexport.



9. Install Mali GPU driver on Debian

Renesas RZ/G2LC MCU is equipped with **Mali-G31** GPU on chip. Debian has a built in support for that GPU through Mesa/X.org project. The productivity of that driver, however, is quite disappointing, especially when you try to use the browser. You can use the evaluation version of the driver, optimized for that GPU, from <u>Renesas</u>. The downside of it, however, is it's evaluation, i.e. it only works for a couple of hours. For the full version you have to contact with Renesas. The driver supplied by Renesas is only compatible with the Wayland display server protocol, keep that in mind if you consider using it.

 You can Install the driver directly by executing the script: In short the script installs Weston, configures a Weston startup service, and finally installs the driver itself.
 → On the target board, get the script for installation: wget https://vekatech.com/os/debian/get_mali.sh.
 → On the target board, make it executable: chmod +x get_mali.sh.

 \rightarrow On the target board, Install the driver:

./get_mali.sh.



10. Launch App on OS start up

The way to do it, is to create a user service, i.e write a text file, with **.service** extension, located at **/usr/lib/systemd/user**.

Let's say the application that needs to be launched is the **Chromium** browser, and the service is named **browser.service**. The contents of that file should look like this:

[Unit]

Description=Chromium (Kiosk Mode) After=graphical-session.target

[Service]

```
Restart=on-failure
RestartSec=5
Environment="WAYLAND_DISPLAY=wayland-1"
```

ExecStart=/usr/bin/chromium -enable-features=UseOzonePlatform
--ozone-platform=wayland --kiosk https://vekatech.com

[Install]

WantedBy=default.target

- To allow the service to be launched on OS start up execute this: systemctl --user enable browser.service.
- To try if the service works as expected, reboot the system: sudo reboot.



Revision overview list	

Revision number	Description changes		
0.1	Initial		

Vekatech Ltd.

63, Nestor Abadzhiev st. 4023 Plovdiv Bulgaria Tel.: +359 (0) 32 262362 info@vekatech.com

www.vekatech.com